



Two joysticks have been detected. These joysticks will be used to control the actions of the backhoe simulator. Click the buttons on each joystick to ensure proper placement.




## Left Joystick



backhoe mode (default):  
this joystick controls the swing and boom

excavator mode:  
this joystick controls the swing and stick



## Right Joystick

